

22. LDM AFTER JAN. 1, 2006



W. S. DARLEY & CO.
REPAIR SERVICE INSTRUCTIONS
TYPE LDM MIDSHIP FIRE PUMP
REMOVAL OF PUMP AND TRANSMISSION
FROM TRUCK CHASSIS

NOTE: It will be beneficial to have assistance present to assist during removal and reinstallation of the pump.

CAUTION: Always have chassis wheels sufficiently blocked with wheel chocks before working on the pump!

1. Unless the truck is raised with approximately three feet of clearance at the running boards, the pump will have to be tipped to get it out from under the truck.
2. Remove the vehicle drive shafts from the pump transmission.
3. Remove all accessories that will prevent lowering the pump and transmission assembly.
4. Drain oil from gear case. Inspect oil for debris, or moisture.
5. Provide a jack or overhead hoist to support pump weight of 800 pounds for removing the pump.
6. Loosen four 5/8" bolts that fasten the suction extensions to the support brackets on the truck frame rails.
7. Loosen all pony suction, tank to pump lines, etc. by unbolting the companion flanges at the suction extensions.
8. Remove the forty 3/8" cap screws that hold the suction heads to the suction extensions.
9. Remove the twelve 3/8" nuts that hold the discharge head to the pump casing.
10. **The pump is ready to be lowered from position.** Some prying may be required to loosen the gasket between the discharge head and pump, and the suction extensions and pump.

LDM PUMP DISASSEMBLY FOR OVERHAUL
Refer to Drawings DLC1404 (pump)

1. Remove Relief Valve and Elbow together. Remove four 3/8-16 NC cap screws and four hex nuts.
2. Remove four 1/4-20 NC cap screws (15) and remove bearing cap (6).
3. Remove bearing (4) using a suitable puller.
4. Make alignment marks to align the inboard and outboard heads (11 and 12) with the pump casing (31).
5. Remove twelve 1/2-13 NC nuts holding outboard suction head to pump casing (31).
6. Pry outboard suction head off pump casing (11). Keep head square with casing bore to avoid damage to parts. Three 5/16-18 NC tapped pusher holes in flange will help flange separation.
7. Remove o-rings (23 and 24) from outboard suction head.
8. Press oil seal (25) out of outboard suction head.
9. If necessary to replace outboard stuffing box (42), remove three 1/4-20 NC stainless steel flat head screws (9) and press outboard stuffing box out of outboard suction head. Discard stuffing box o-ring (19).
10. If necessary to replace, remove seal ring (35) from outboard suction head (11).
11. Remove impeller retaining ring (32) from impeller shaft (36).
12. Mark outboard side of impeller (16). Slide impeller off impeller shaft (36).

13. Remove second impeller retaining ring (32).
14. Remove twelve 1/2-13 NC nuts holding pump casing (31) to inboard suction head (12).
15. Pry pump casing (31) away from inboard suction head (12). Three 5/16-18 NC pusher holes in flange will help separation.
16. Remove o-rings (23 and 24) from inboard suction head.
17. Remove four 3/8-16 NC cap screws (14) and bearing cap (12) from gear case (2). Two 5/16-18 NC tapped pusher holes in flange will help separation. Discard o-ring (11).
18. Remove three 1/2-13 NC and two 3/8-16 NC cap screws holding inboard suction head to gear case (2). Separate the two parts and slide the inboard head/impeller shaft assembly away from gear case.
19. Remove impeller shaft assembly (36) from inboard suction head.
20. Press oil seal (26) out of inboard suction head.
21. If necessary to replace inboard stuffing box (41), remove three 1/4-20 NC stainless steel flat head screws (9) and press stuffing box out of inboard head. Discard stuffing box o-ring (19).
22. If necessary to replace, remove seal ring (35) from inboard suction head.
23. Press bearing (5) off impeller shaft (36).
24. Press pinion gear (8) and pinion spacers (7 and 9) off impeller shaft (36). Note spacer locations.

LDM TRANSMISSION DISASSEMBLY FOR OVERHAUL
Refer to Drawings DLC0608

1. Remove air power shift option if equipped.
2. Place the gear case assembly on a bench.
3. Remove twelve 5/16 NC cap screws and transmission cover (103) from side of gear case (2). Discard gasket.
4. Remove lock nuts (31) and slide universal joint yokes (32) from input shaft (51) and output shaft (55). Discard lock nuts (31).
5. Remove eight 3/8-16 NC socket head cap screws and separate rear bearing bracket (58) assembly from gear case.
6. Cut safety wire (47) and remove lock bolt (46) from shift yoke (45). Remove yoke and shift bar (43) from gear case.
7. Tap bearing (54) off transmission shaft (51) with sliding clutch gear (53) or using a suitable puller.
8. Remove four 3/8-16 NC cap screws (35) and separate front bearing bracket (36) from gear case. Discard o-ring (11).
9. Press oil seal (34) out of bearing bracket (36).
10. Remove retaining ring (49) from drive gear (52).
11. Push transmission shaft (51) out of drive gear toward input side of transmission.
12. Press bearing (37), spacer (48) and bearing (50) off transmission shaft (51) all at once.
13. Press second bearing (50) off transmission shaft (51).
14. Remove eight 3/8-16 NC cap screws and bearing caps (21 and 29). Discard o-rings (22).
15. Place gear case with tail shaft side down on an arbor press table and push idler gear shaft (25) through idler gear (26), spacers (27 and 28), and bearing (23). Use a pusher 1-5/32 O.D. or less by 3-5/8 long.
16. Press bearing (23) off idler gear shaft (25).

REAR BEARING BRACKET DISASSEMBLY

17. Press rear drive shaft (55) out of bearing bracket (58) which removes bearing (62) from shaft.
18. Remove four 3/8 – 16NC cap screws (65) and separate bearing cap (64) from rear bearing bracket (58). Discard o-ring (63).
19. Press bearing (56) off rear drive shaft (55).
20. Remove oil seals (57) out of rear bearing bracket (58).
21. Press bearing (62) out of bearing cap (64).
22. Press oil seal (34) out of bearing cap (64).

PUMP PARTS INSPECTION AND MEASUREMENT

1. Clean all parts and examine carefully for wear or deterioration. Replace all questionable parts.
2. Measure the impeller seal rings and impellers for wear. Use the following table for comparison:

Impeller Seal Ring O.D.	5.235 - 5.237
Impeller Seal Ring I.D.	4.999 – 5.001
Stationary Seal Ring O.D.	5.249 – 5.251
Stationary Seal Ring I.D.	4.985 – 4.987
Clearance O.D.	0.012 – 0.016
Clearance I.D.	0.012 – 0.016

3. If clearance exceeds 0.025" on diameter, impeller seal rings can be restored to original size by soldering a ring over trued surface which retains 0.090" min. wall thickness. Stationary seal rings should also be replaced or you may purchase undersize seal rings. Call customer service for details.
4. Measure the impeller shaft and stuffing boxes for wear. Use the following table for comparison:

	Outboard	Inboard
Impeller Shaft Diameter	1.561 – 1.562	1.749 – 1.750
Stuffing Box Bore - new	1.571 – 1.572	1.759 – 1.760
Stuffing Box Bore - max	1.575	1.763
Clearance - original	0.005 – 0.008	0.009 – 0.011
Clearance - max	0.014	0.014

5. Measure bearing housing bores for proper size. Use the following table for comparison. If any bore exceeds the high limit by 0.0005", the part must be replaced.

Part	Rep. Number	Original Diameter
Bearing Cap	29	2.4409 – 2.4416
Bearing Cap	21	2.4409 – 2.4416
Bearing Cap	12	2.8346 – 2.8353
Front Bearing Bracket	36	4.7244 – 4.7252
Drive Gear	52	3.9370 – 3.9379
Rear Bearing Bracket	58	4.3307 – 4.3316
		4.7244 – 4.7253
Output Shaft	55	2.4409 – 2.4416
Outboard Bearing Cap	6	2.8346 – 2.8353
Suction Head	11 & 12	4.3307 – 4.3316

6. Measure shaft bearing journals for proper size. Use the following table for comparison. The low limits under the bearings is required to insure a press fit with the inner bearing race.

Part	Rep. Number	Original Diameter
Impeller Shaft	36	1.1812 – 1.1816
		1.9686 – 1.9690
		1.5749 – 1.5753
Idler Gear Shaft	25	1.1812 – 1.1816
Transmission Shaft	51	0.9844 – 0.9848
		2.5592 – 2.5597
Output Shaft	55	2.7560 – 2.7565

7. The original impeller shaft diameter under the pinion gear is 1.7490 to 1.7495. The original pinion gear bore is 1.7495 to 1.7500 providing a 0.0000 to 0.0010 clearance. The parts are still serviceable up to 0.0015 clearance. Pinion gear may be reversed to work other side of gear teeth.
8. The original idler gear shaft diameter under the idler gear is 1.7495 to 1.7500. The original idler gear bore is 1.7495 to 1.7500 providing a 0.0005 press fit to 0.0005 clearance. The parts are still serviceable up to 0.0010 clearance. Idler gear may be reversed to work other side of gear teeth.

**IF FURTHER INFORMATION IS NEEDED, CALL W.S. DARLEY & CO. AT
CHIPPEWA FALLS, WI. AT 800-634-7812 or 715-726-2650**

LDM TRANSMISSION ASSEMBLY
Refer to Drawings DLC0608 (transmission)

1. If necessary to install, apply a light coat of oil to tachometer drive nut (17) and press it evenly into the hole at the end of idler gear shaft (25). The shoulder end of the idler shaft is at the output shaft side of gear case. Tachometer drive nut is opposite the pump side of gear case and extends 3/8 “ beyond end of shaft.
2. Place gear case (2) on bench with pump side down and place idler gear (26) inside gear case. Tachometer side is opposite to pump mounting side.
3. Apply a light coat of oil to idler gear shaft (25). Place key (24) in idler gear shaft keyway. Align with key slot in gear (26) and press shaft evenly into idler gear bore until shaft shoulder is tight against side of gear.
4. Apply a light coat of oil to bore of bearing (23) on tachometer side and press evenly on idler gear shaft (25) until tight against shaft shoulder. Three bearing support washers X5144-2 will help the bearing from cocking.
5. Install dowel pin (20) into gear case.
6. Install bearing cap (21) and o-ring (22) with four 3/8-16 cap screws (18) lockwashers (19). Remove support washers. Torque to 23 ft/lb.
7. Turn gear case over and place spacers (27) and (28) on idler gear shaft (25).
8. Apply a light coat of oil to bore of second bearing (23) and press evenly onto idler gear shaft until spacers, idler gear, and inner race of bearing are tight together. Three bearing support washers X5144-2 will help the bearing from cocking.
9. Install bearing cap (29) and o-ring (22) with four 3/8-16 cap screws (18) lockwashers (19). Remove support washers. Torque to 23 ft/lb.
10. Place oil seal (56) on assembly plug X3852/X3852-1 and plug into end of tachometer drive nut (55). Press oil seal into bearing cap (57) with lip spring of seal facing bearing. Lubricate oil seal lip.
11. Press two bearings (50) onto transmission shaft (51) until inner races are tight against shaft shoulders.
12. Oil lubricate bore of drive gear (52) and place inside gear case. Clutch gear side to output side.
13. Slide transmission shaft (51) with bearings (50) into drive gear (52). Install retaining ring (49).
14. Slide spacer (48) over transmission shaft (51) and against bearing (50). Press bearing (37) onto transmission shaft against spacer.
15. Press oil seal (34) into front bearing bracket (36), flush with face of bracket, with lip spring of seal facing bearing. Lubricate oil seal lip.
16. Install o-ring (11) onto front bearing bracket (36). Tap bearing bracket over bearing (37) and against gear case. Tap transmission shaft from rear until bearing is seated in front bearing bracket. Torque to 23 ft/lb.
17. Lubricate bore and place sliding clutch gear (53) on spline of transmission shaft (51) with external gear teeth forward.
18. Press bearing (54) onto transmission shaft (51) until tight against shaft shoulder.
19. Apply silicone lubricant to o-ring (39) and install in groove in gear case shift bar hole. Lubricate shift bar hole.
20. Lubricate shift bar (43) with oil and slide into gear case.
21. Saturate oil wicks in shift yoke (44) ears with oil.

22. Place shift yoke (45) in groove of sliding clutch gear (53) and slide shift bar (43) through hole in yoke. Align groove in shift bar with bolt hole in yoke. Apply Loctite 243 (or equivalent) to the threads of lock bolt and install in shift yoke and torque to 23 ft/lbs. Attach safety wire through hole in head of lock bolt and in end groove of shift bar.
23. Install retaining rings on front side of shift bar outside of gear case (2). See drawing DGM0700 which shows sharp corner side of retaining ring in proper position to take thrust load.
24. Slide front yoke (32) with flinger (33) attached onto drive shaft (55). Install universal joint retaining nut (31).


REAR BEARING BRACKET ASSEMBLY

25. Press oil seal (57) into rear bearing bracket (58) with lip springs of seal facing bearings. Be sure to press the oil seals in until they are flush or slightly below the face of the rear bearing bracket they are sealing. Lubricate oil seal lip.
26. Press bearing (56) onto rear drive shaft (55) at truck gear end.
27. Place oil seal assembly sleeve X3851 over splined end of rear drive shaft (55) or wrap spline with shim stock to prevent damage to oil seals. Make sure the largest diameter step at splined end of shaft is covered. Slide shaft into rear bearing bracket (58). Remove sleeve or shim stock. Place bearing backup washer (62) on rear drive shaft.
28. Press the double shielded bearing (63) onto the rear drive shaft (55) against backup washer (62).
29. Apply a thin layer of Loctite Master Gasket 518 (or equivalent) to the flange of rear bearing bracket (58). Place rear bearing bracket assembly into position at rear of gear case so bearing (54) enters bore at gear end of tail shaft (55). Use two 3/8-16 NC x 1-1/2 cap screws (60), and lock washers (59) to draw flange up to gear case mounting surface. Apply Loctite 243 (or equivalent) to, and install remaining five 3/8-16 NC x 1-1/2 cap screws and lock washers and one 3/8-16 NC x 1 1/4 socket head cap screw (61) and high collar washer (59) at the housing extension flange. Torque to 23 ft/lb.
30. Press oil seal (34) into bearing retainer (65) with lip spring of seal facing bearing. Lubricate oil seal lip. Apply Loctite 603 (or equivalent) to bore of the bearing retainer (65), taking care not to spill any on the faces that touch the sides of the bearing (34).
31. Slide o-ring (64) over bearing (63) until it is touching the rear bearing bracket (58).
32. Attach bearing retainer (65) to rear bearing bracket (58) with four 3/8-16 NC x 1-3/4 cap screws (66), and lock washers (19). Torque to 23 ft/lb.
33. Slide rear yoke (32) with flinger (33) attached onto rear drive shaft (55). Install universal joint retaining nut (31), and torque both universal joint retaining nuts to 150 - 200 ft/lb.


LDM PACKING PUMP ASSEMBLY

Refer to Drawings DLC1404

1. Note spacer locations below for pump forward or pump rear configuration. Install spacer if required (7). Apply a light coat of oil to impeller shaft (36). Place pinion key (6) in impeller shaft keyway, align with keyway in pinion gear (8). Press shaft evenly into pinion gear until shaft shoulder is tight against side of gear.



pump forward of gear case



pump rear of gear case

2. Install spacer(s) (7 and 9) next to gear (8).
3. Apply a light coat of oil to bore of bearing (10). Press bearing evenly onto impeller shaft (36) until spacers and gear are tight to shoulder of shaft.
4. Apply a light coat of oil to bore of bearing (5). Press bearing onto impeller shaft (36) until inner race of bearing is tight against shaft shoulder..
5. Apply a silicone lubricant to stuffing box o-ring (19), and place in groove of inboard head.
6. Align stuffing box (41) with inboard suction head (12) by placing three 1/4-20 NC x 3 cap screws through mounting holes of stuffing box and screw into corresponding tapped holes of inboard head. Press stuffing box into position using tool X5950 and remove alignment cap screws. Apply Loctite 243 (or equivalent) to threads of, and install three 1/4-20 NC stainless steel flat head screws (14) to secure stuffing box in inboard suction head. Torque to 72 in-lbs.
7. Apply Loctite 609 to O.D. of seal ring (35), press into inboard suction head (12) until seated tight in pocket.
8. Place water slinger (37) in position on inboard stuffing box (41).
9. Press oil seal (26) into inboard suction head (12) with lip spring of seal facing bearing. Lubricate oil seal lip.
10. Insert impeller shaft (36) assembly into inboard stuffing box (41). Tap in until bearing (5) is seated in bearing pocket of inboard suction head.
11. Move water slinger (37) into its groove on impeller shaft (36).
12. Apply o-ring (22) to pilot of inboard suction head (12).
13. Slide impeller shaft-suction head assembly into position with gear case (2). Line up inboard suction head so it is square with gear case.
14. Attach inboard suction head to gear case with one 1/2-13 NC x 2 (5) cap screw and lock washer on top, two 1/2-13 NC x 1-1/2 cap screws (3) and lock washers at sides, and two 3/8-16 NC x 1 cap screws (14) and lock washers (19) at bottom. Use Loctite 243 (or equivalent) on the threads.
15. Position o-ring (11) against pilot of bearing cap (12).

16. Apply Loctite 243 (or equivalent) to four 3/8-16 NC x 1 (14) cap screws and attach bearing cap (12) to gear case (2).
17. Apply a silicon lubricant to suction head o-ring (23) and place on inboard suction head.
18. Place o-ring (24) on suction head pilot.
19. Push pump casing (31) into position on inboard suction head (12), stop before head is all the way on and start the nuts (14) on the studs (40). Snug up two nuts on top and two nuts on bottom.
20. Place impeller retaining ring (32) on impeller shaft (36) with sharp edge toward gear case.
21. Slide impeller (16) onto impeller shaft (36). Note rotation of impeller.
22. Place second impeller retaining ring (32) on impeller shaft (36) with sharp edge away from impeller (16).
23. Apply a silicone lubricant to stuffing box o-ring (19), and place in groove of outboard head (11)
24. Align stuffing box (42) with outboard suction head (11) by placing three 1/4-20 NC x 3 cap screws through mounting holes of stuffing box and screw into corresponding tapped holes of outboard head. Press stuffing box into position using tool X5950 and remove alignment cap screws. Apply Loctite 243 (or equivalent) to the threads of, and install three 1/4-20 NC stainless steel flat head screws (9) to secure stuffing box in outboard suction head. Torque to 72 in-lbs.
25. Apply Loctite 609 to O.D. of seal ring (35), press into outboard suction head (11) until seated tight in pocket.
26. Apply a silicon lubricant to suction head o-ring (23) and place on outboard suction head.
27. Place o-ring (24) on suction head pilot.
28. Push outboard suction head (11) onto pump casing (31). Start twelve 1/2-13 NC nuts (14) on the studs (40). Snug up two nuts on top and two nuts on bottom.
29. Line up alignment marks on suction heads (11 and 12) with marks on pump casing (31) or use a straightedge to align inboard and outboard heads. Tighten all nuts.
30. Push water slinger (38) onto impeller shaft (36).
31. Press oil seal (25) into outboard suction head (11). Insert with lip spring of seal facing bearing. Lubricate oil seal lip.
32. Apply oil to end of impeller shaft (36) and tap bearing (4) onto shaft.
33. Apply gasket eliminator to flange surface of bearing cap (6). Tap bearing cap over bearing (4) and attach to outboard suction head with four 1/4-20 NC x 7/8 cap screws (15) and lock washers (44).
34. Install relief valve if equipped.


INSTALLING PUMP IN TRUCK CHASSIS

- Reverse the procedures outlined under removal instructions.
- Fill gear case with SAE80W/90 gear lube oil to the level located in the dipstick.


**IF FURTHER INFORMATION IS NEEDED, CALL W.S. DARLEY & CO. AT
CHIPPEWA FALLS, WI. AT 800-634-7812 or 715-726-2650**

LDM MECHANICAL SEAL PUMP ASSEMBLY
Refer to Drawing DLC1402

1. Note spacer locations below for pump forward or pump rear configuration. Install spacer if required (7). Apply a light coat of oil to impeller shaft (36). Place pinion key (6) in impeller shaft keyway, align with keyway in pinion gear (8). Press shaft evenly into pinion gear until shaft shoulder is tight against side of gear.



pump forward of gear case



pump rear of gear case




2. Install spacer(s) (7 and 9) next to gear (8).
3. Apply a light coat of oil to bore of bearing (10). Press bearing evenly onto impeller shaft (38) until spacers and gear are tight to shoulder of shaft.
4. Apply a light coat of oil to bore of bearing (5). Press bearing onto impeller shaft (38) until inner race of bearing is tight against shaft shoulder..
5. Apply a silicone lubricant to stuffing box o-ring (22), and place in groove of inboard head.
6. Align mechanical seal housing (17) with inboard suction head (14) by placing three 1/4-20 NC x 3/4" cap screws through mounting holes of housing and screw into corresponding tapped holes of inboard head. Press housing into position using tool X5950 and remove alignment cap screws. Apply Loctite 243 (or equivalent) to threads of, and install three 1/4-20 NC stainless steel flat head screws (12) to secure mechanical seal housing in inboard suction head. Torque to 72 in-lbs.
7. Carefully unwrap the inboard mechanical seal (36) using extreme care not to damage or contaminate the lapped surfaces of the mating or primary ring. While holding the mating ring by the inside diameter, lubricate the outside diameter o-ring with P-80 Rubber Lubricant, KY jelly or equivalent water-soluble lubricant. Insert mating ring into housing with mirror surface facing out. Place clean cardboard circle on ring and press squarely into housing. Confirm that mating ring has been seated firmly into pocket.
8. Apply Loctite 609 to O.D. of seal ring (37), press into inboard suction head (14) until seated tight in pocket.
9. Place water slinger (40) in position on inboard seal housing (17).
10. Press oil seal (29) into inboard head (14) with lip spring of seal facing bearing. Lubricate oil seal lip.

11. Insert impeller shaft-suction head assembly through water slinger and mechanical seal housing, being careful to avoid contact with the seal mating ring. Tap on end of pump shaft with a rubber mallet until bearing is seated in bearing pocket in inboard head. Position slinger (40) into groove.
12. Apply light grease or oil to head o-ring (11) and position in groove.
13. Slide suction head and shaft assembly into position in gear case. Make sure the pump shaft does not slide out of the outboard head while assembling the inboard suction head to the gear-case. Align head squarely with gear case.
14. Attach inboard suction head (14) to gear-case with one 1/2NC x 2 cap screw (5) on top, two 1/2NC x 1-1/2 cap screws (3) at sides, and two 3/8NC x 1 cap screws (14) on bottom.
15. Position o-ring (11) against pilot of bearing cap (12).
16. Apply Loctite 243 or equivalent to four 3/8NC x 1 cap screws (14), and attach bearing cap (12) to gear case.
17. Being careful not to damage or contaminate the lapped sealing surface, lubricate the inboard head primary ring (36) elastomer bellows with P-80 Rubber Lubricant, KY jelly or equivalent water-soluble lubricant. Apply thin coat of lubricant to impeller shaft where bellows (36) seats on the shaft. With lapped sealing surface facing mating ring, slide primary ring bellows assembly squarely onto shaft.
18. Using properly sized pusher tube, carefully push primary ring bellows (36) assembly onto the shaft until primary ring contacts the mating ring. Use care to avoid hard contact between the two surfaces.
19. Insert 3/16 sq. x .75 stainless steel key (20) into keyway.
20. Slide seal compression spring (discard thin brass spring holder) onto shaft and into position on primary ring.
21. Slide enclosure (10) onto shaft and align with drive key (20).
22. Using appropriately sized retaining ring pliers, expand retaining ring (33) just enough so it will slide over the shaft up to enclosure (10) with sharp edge of retaining ring facing impeller. Compressing spring, continue to slide enclosure and retaining ring toward the seal until retaining ring (33) snaps into groove. Confirm the proper placement and security of the retaining ring.
23. Apply silicone lubricant to pump casing seal o-rings (26) and (27) and position on inboard head.
24. Place inside impeller retaining ring (32) on impeller shaft with sharp edge of ring facing the gear case.
25. Place (1) 3/8NC x 1.25 HHCS through the passenger side suction extension-mounting flange. This is necessary due to reduced clearance once the pump casing is installed.
26. Apply a thin layer of silicone lubricant to pump casing (31) bore surfaces. Assemble casing (31) onto inboard head and secure with (12) 1/2-13NC hex nuts (15).

27. Slide impeller (19) onto shaft (38). Note rotation of impeller.
28. Place second impeller retaining ring (32) on impeller shaft (38) with sharp edge facing away from the impeller.
29. Apply a silicone lubricant to stuffing box o-ring (22), and place in groove of outboard head (13).
30. Align mechanical seal housing (18) with outboard suction head (13) by placing three 1/4-20 NC x 3 cap screws through mounting holes of housing and screw into corresponding tapped holes of inboard head. Press housing into position using tool X5950 and remove alignment cap screws. Apply Loctite 243 (or equivalent) to threads of, and install three 1/4-20 NC stainless steel flat head screws (12) to secure mechanical seal housing in outboard suction head. Torque to 72 in-lbs.
31. Carefully unwrap the inboard mechanical seal (35) using extreme care not to damage or contaminate the lapped surfaces of the mating or primary ring. While holding the mating ring by the inside diameter, lubricate the outside diameter o-ring with P-80 Rubber Lubricant, KY jelly or equivalent water-soluble lubricant. Insert mating ring into housing (18) with mirror surface facing out. Place clean cardboard circle on ring and press squarely into housing. Confirm that mating ring has been seated firmly into pocket.
32. Apply Loctite 609 to O.D. of seal ring (37), press into outboard suction head (13) until seated tight in pocket.
33. Apply silicone lubricate to casing seal o-rings (26) and (27) and position on outboard head.
34. Assemble retaining ring (32), sharp edge of retaining ring facing impeller (19).
35. Insert key (20), and enclosure (11) to shaft (38).
36. Slide mechanical seal (11) spring holder onto shaft up to the retaining ring (32).
37. Slide spring onto spring holder (11).
38. Being careful not to damage or contaminate the lapped sealing surface, lubricate the outboard primary ring (35) elastomer bellows with P-80 Rubber Lubricant, KY jelly or equivalent water-soluble lubricant. With lapped sealing surface facing away from the impeller, slide primary ring squarely onto shaft. Position spring on bellows pilot. Using a properly sized pusher tube, (ID larger than seal surface but smaller than brass seal holder), push the primary ring onto the shaft 1/4" past the slinger groove.
39. Carefully position and assemble previously prepared outboard head assembly onto shaft and into pump casing. Do not allow shaft to disturb or contaminate already positioned mechanical seal mating ring. It is important to insert head pilot into casing squarely without cocking. Tighten nuts equally until all are tight.
40. Push water slinger (39) onto pump shaft (38) and position in groove.
41. Push oil seal (28) into head with open side toward outboard bearing (4). Lubricate oil seal lip.
42. Apply oil to end of pump shaft (38) and tap bearing (4) onto shaft until tight against shaft shoulder.
43. Lubricate bore of bearing cap (6). Apply gasket eliminator to flange surface of bearing cap (6). Tap bearing cap (6) over bearing (4) and attach to outboard head with four 1/4-20NC x 7/8 cap screws and lock washers.

REV.	DESCRIPTION	DATE	LOG. NO.	WORK

NO.	DESCRIPTION	PART NO.	QTY.
1	ASSTY - FLANGE COVER, BLANK CI	-	1
2	ASSTY - FLANGE C'VR, BLNK, O-RING	-	1
3	ASSTY - FLANGE - 4" IPT, CI	-	1
4	BEARING-BALL, 306STF	-	1
5	BEARING-BALL, 310STF	-	1
6	CAP - BEARING, LDMVE	-	1
7	COVER - RELIEF VALVE	-	1
8	DRAINCOCK - 0.250 NPTM, 9HC BR	-	1
9	ELBOW - RELIEF VALVE, LDM	-	1
10	ENCLOSURE - MECH SEAL, LDM	-	1
11	ENCLOSURE - MECH SEAL, LDM	-	1
12	FMS - 250-20 X 0.63, SS	-	6
13	HEAD - SUCTION, LDM, MECH SEAL	-	1
14	HEAD - SUCTION, LDM, MECH SEAL	-	1
15	HEX NUT - 500-13, SR 2	-	24
16	HMS - 250-20 X 0.75, GR5	-	4
17	HOUSING - MECH SEAL, LDM	-	1
18	HOUSING - MECH SEAL, LDM	-	1
19	IMPELLER - LDM, MIXED FLOW	-	1
20	KEY - 50, 0.19 X 0.75 316SS	-	2
21	O-RING - 1.47 X 1.71 X 0.09	-	2
22	O-RING - 3.00 X 3.12 X 0.06	-	2
23	O-RING - 3.50 X 3.69 X 0.09	-	2
24	O-RING - 3.75 X 4.00 X 0.12	-	2
26	O-RING - 8.50 X 8.75 X 0.12	-	2
27	O-RING - 9.00 X 9.25 X 0.12	-	2
28	OIL SEAL - 1.500 ID X 3.005 OD	-	1
29	OIL SEAL - 1.875 ID X 3.005 OD	-	1
30	PLUG - PIPE, 0.125, SST SOC HD	-	4
31	PUMP CASING - LS	-	1
32	RING - RETAINER, 5100-150HSS2	-	1
33	RING - RETAINER, 5100-175HSS2	-	3
34	SCREEN STRAINER	-	1
35	SEAL - SHFT, 1.500", WELD SPRG	-	1
36	SEAL - SHFT, 1.875", WELD SPRG	-	1
37	SEAL RING - LDM	-	2
38	SHAFT - PUMP, LDM, MECH SEAL	-	1
39	SLINGER - WATER, 1.421	-	1
40	SLINGER - WATER, 1.786	-	1
41	STRAINER - FITTING	-	1
42	STUD - 0.500-13 X 1.750, GR5	-	24
43	WASHER - LOCK, 0.250 ID	-	4
44	HEAD ASSTY - LDM DIS W/4" FLG	-	1




SECTION A-A

REMOVE SHARP EDGES	INCH (SMALL METERS)	DO NOT SCALE PRINT
SEE SECTION IS THE PROPERTY OF W.S. DORVY & CO. ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED	DO NOT SCALE PRINT	DO NOT SCALE PRINT
OLD PART NO.	TOLERANCE	SCALE
NEW PART NO.	AS SHOWN	SCALE
MATERIAL NO.	BY	DATE
PATTERN NO.	BY	DATE
DATE 09 DEC 83	DATE 09 DEC 83	SCALE 1/2


DLCH402

REVISED		DATE	ENG. NO.	DWG. NO.


NO.	DESCRIPTION	PART NO.	QTY.
1	ASSY - FLANGE COVER, BLANK C1	-	1
2	ASSY - FLANGE CVR, BLNK, O-RING	-	1
3	ASSY - FLANGE, 4 NPT, C1	-	1
4	BEARING-BALL, 308SFF	-	1
5	BEARING-BALL, 310SFF	-	1
6	CAP - BEARING, LOW/IE	-	1
7	DRAINCOCK - 0.250 NPTM, 9HC BR	-	1
8	ELBOW - RELIEF VALVE, LHM	-	1
9	FIMS - .250-20 X 0.83, SS	-	6
10	ISLAND NUT - A	-	2
11	HEAD - SUCTION, LHM, PACKING	-	1
12	HEAD - SUCTION, LHM, PACKING	-	1
13	HEAD ASSY - LHM DIS W/4" FLG	-	1
14	HEX NUT - .500-13, GR 2	-	24
15	IMCS - .250-20 X 0.75, GR5	-	4
16	IMPELLER - LHM, MIXED FLOW	-	1
17	IMP - LHM, SS, BY FLANGE BLIND	-	1
18	O-RING - 1.41 X 1.11 X 0.09	-	1
19	O-RING - 3.00 X 3.12 X 0.08	-	2
20	O-RING - 3.50 X 3.69 X 0.09	-	2
21	O-RING - 3.75 X 4.00 X 0.12	-	1
22	O-RING - 5.00 X 5.25 X 0.12	-	1
23	O-RING - 8.50 X 8.75 X 0.12	-	2
24	O-RING - 9.00 X 9.25 X 0.12	-	2
25	OIL SEAL - 1.500 ID X 3.005 OD	-	1
26	OIL SEAL - 1.815 ID X 3.015 OD	-	1
27	PACKING 8927 - PELLET	-	10
28	PACKING CILINDER - B	-	2
29	PISTON-GLAND STUD, S	-	2
30	PLUG - PIPE, 0.125, SST SOC HD	-	4
31	PUMP CASING - LS	-	1
32	RING - RETAINER, 5100-175H652	-	2
33	SCREEN STRAINER	-	1
34	SCREW - PACKING	-	2
35	SEAL RING - LHM	-	2
36	SHAFT - PUMP, LHM	-	1
37	SLEINGER - WATER, 1.421	-	1
38	SLEINGER - WATER, 1.421	-	1
39	STRAINER - FITTING	-	1
40	STUD - 0.500-13 X 1.750, GR5	-	24
41	STUFFING BOX - LHM	-	1
42	STUFFING BOX - LHM	-	1
43	VALVE - 3" R.V. BASIC	-	1
44	WASHER - LOCK, 0.250 ID	-	4




SCALE 3/16




SCALE 3/16



SECTION C-C



SECTION B-B



SECTION A-A



REV. NO.	REV. DATE	REV. BY	REV. FOR

DESIGNER	DR. P. H. W.	SCALE	3/16
CHECKER	J. W. S.	DATE	12-28-63
APPROVED	J. W. S.	PROJECT NO.	100-1000
TITLE	W.S. DeLong & Co.	WORKING DRAWING NO.	100-1000-1
DESCRIPTION	PUMP - LHM TANK TO PUMP	DATE	12-23-63
SCALE	3/16	PROJECT	100-1000
PROJECT	100-1000	SCALE	3/16
PROJECT	100-1000	SCALE	3/16

REMOVE SHARP EDGES
 ALL DIMENSIONS IN INCHES UNLESS OTHERWISE SPECIFIED
 PRODUCTIONS IN PRODUCTION IS PROHIBITED

SCALE 3/16
 DLCK404

REV. NO.	DESCRIPTION	DATE	CHK. NO.	CHK. BY
1				




NO.	DESCRIPTION	PART NO.	QTY.
1	BEARING-BALL, 310SF	172101	1
2	GEARCASE - LOW/MID, PUMP FWD	4802300	1
3	HMCS - 500-13 x 1.75, OR8	5400048	2
4	WASHER - LOCK, 0.500 ID	3603565	3
5	HMCS - 500-13 x 2.00, OR8	5400049	1
6	KEY - 50, 0.75 x 2.50, OR2	3602448	1
7	SPACER - 1.75 x 2.40 x 0.86	3386700	1
8	GEAR - PINION, N, 20 PA	2178801	1
9	SPACER - 1.57 x 2.00 x 0.71	3393400	1
10	BEARING-BALL	1720903	1
11	O-RING - 5.00 x 5.25 x 0.12	3401227	2
12	CAP - BEARING, PUMP SHFT	2384292	1
13	WASHER	4403400	1
14	HMCS - 375-16 x 1.00, OR8	5401023	5
15	PLUG - TAPER, .88-100MS	1142101	1
16	OIL SEAL - 0.375 ID x 0.680 OD	3603524	1
17	NUT - CHELL DRIVE, 0.104	1143900	1
18	HMCS - 375-16 x 0.86, OR5	5400325	8
19	WASHER - LOCK, 0.375 ID	3603503	16
20	PN - DWELL, .250 x 0.62, OR8	3603401	1
21	SPACER - BEARING, IDLER TACH	2303833	2
22	BEARING - BALL, 2.50 x 2.50 x 0.50	1720904	2
23	BEARING - BALL, 2.50 x 2.50 x 0.50	1720905	2
24	SAFT - 50, 0.69 x 0.64	5400308	1
25	SAFT - 50, 0.69 x 0.64	5400309	1
26	GEAR - BRNLS, 65P, RPP, 20DG PA	2173700	1
27	SPACER - 1.75 x 2.0 x 1.42	3392754	1
28	BEARING CAP, 101.0	3392754	1
29	BEARING CAP, 101.0	3392754	1
30	SHIELD - WATER, RUM/DOWN	3203300	1
31	LOCKWIT	4814600	2
32	END YOKE	4813600	2
33	FINGER - WATER	3291000	2
34	OIL SEAL - 2.838 ID x 3.756 OD	3605403	2
35	HMCS - 375-16 x 1.25, OR5	5400317	4
36	BRACKET - BEARING, FOWN, N	2384403	1
37	BEARING-BALL, 2138FF	1721401	1
38	RING - RETAINER, 5160-87	3604003	1
39	O-RING - 0.88 x 1.12 x 0.12	3601212	1
40	DIPSTICK - 40232.5 THR D	4219000	1
41	O-RING - 2.000 x 2.500 x 2.500	3601702	1
42	PLUG - PIPE, 0.375, MFG, SOC, HD	1000510	1
43	SHIFT BAR - PSM	1103900	1
44	PELLET - OIL WICK	4403900	6
45	SHIFT YOKE	1103700	1
46	LOCK BOLT - SHIFT BAR	1104000	1
47	WIRE - SAFETY	1102819	1
48	SPACER - 2.56 x 2.88 x 1.56	3384704	1
49	RING - RETAINER, 40500-393	3604038	1
50	BEARING-BALL, 11385FF	1723400	2
51	SHFT - TRANSMISSION	5089701	1
52	GEAR - BRNLS, N, RPP, 20 DEGREE PA	2174167	1
53	GEAR - SLIDING CLUTCH, N	2410800	1
54	BEARING-BALL, 3058FF	1721700	1
55	SHFT - TRANSMISSION	5089500	1
56	BEARING-BALL, 11465FC	1723502	1
57	OIL SEAL - 2.750 ID x 3.500 OD	3605511	2
58	BRACKET - BEARING, REAR NO BRK	2384700	1
59	WASHER - LOCK, INC, 0.375 ID	3603512	8
60	HMCS - 375-16 x 1.25, OR8	5400254	7
61	WASHER - 2.56 x 3.00 x .09 STL	3603023	1
62	BEARING-BALL, 2138FF	1721400	1
63	O-RING - 4.50 x 4.69 x 0.09	3601105	1
64	REAR BEARING CAP, N	2385106	1
65	HMCS - 375-16 x 1.75, OR5	5400039	4
100	HEAD - SECTION, LOW, MECH SEAL	2807700	1
101	OIL SEAL - 1.875 ID x 3.005 OD	3600540	1
102	SHFT - PUMP, LOW	5089303	1
103	TRANSMISSION COVER ASSEMBLY	4801301	1
104	AIR CYLINDER - 1.75 BORE	4100201	1

INCH	(MILLIMETERS)
REMOVE SHARP EDGES	
REMOVE BURRS	
DO NOT SCALE PRINT	
SCALE	1/2
DATE	27 JUN 83
DESIGNER	DL C0608

NOTES:
 - DIPSTICK, OIL WICK PELLETS, DOWEL PINS AND FASTENERS SHOWN ON EXPLODED VIEW (SHEET TWO)
 - BEARINGS WITH SINGLE SHIELDS - SHIELDED SIDE GOES TOWARD OUTSIDE OF TRANSMISSION

103	REF
104	REF
105	REF
106	REF
107	REF
108	REF
109	REF
110	REF
111	REF
112	REF
113	REF
114	REF
115	REF
116	REF
117	REF
118	REF
119	REF
120	REF
121	REF
122	REF
123	REF
124	REF
125	REF
126	REF
127	REF
128	REF
129	REF
130	REF
131	REF
132	REF
133	REF
134	REF
135	REF
136	REF
137	REF
138	REF
139	REF
140	REF
141	REF
142	REF
143	REF
144	REF
145	REF
146	REF
147	REF
148	REF
149	REF
150	REF
151	REF
152	REF
153	REF
154	REF
155	REF
156	REF
157	REF
158	REF
159	REF
160	REF
161	REF
162	REF
163	REF
164	REF
165	REF
166	REF
167	REF
168	REF
169	REF
170	REF
171	REF
172	REF
173	REF
174	REF
175	REF
176	REF
177	REF
178	REF
179	REF
180	REF
181	REF
182	REF
183	REF
184	REF
185	REF
186	REF
187	REF
188	REF
189	REF
190	REF
191	REF
192	REF
193	REF
194	REF
195	REF
196	REF
197	REF
198	REF
199	REF
200	REF



NO.	DESCRIPTION	PART NO.	QTY.
1	BEARING-BALL, 310ST	1722101	1
2	GEARCASE - LHM/LDMC, PUMP FND	1802300	1
3	HMCs - .500-13 x 1.75, GR5	5400048	2
4	WASHER - LOCK, 0.500 ID	3603505	3
5	HMCs - .500-13 x 2.00, GR5	5400049	1
6	KEY - .50 - .25 x 2.50, GR2	3602438	1
7	SPACER - 1.75 x 2.40 x 0.86	3308700	1
8	GEAR - PINION, N, 8DP, 20 PA	2717801	1
9	SPACER - 1.57 x 2.00 x 0.71	3303400	1
10	BEARING-BALL	1722003	1
11	O-RING - 5.00 x 5.25 x 0.12	3601227	2
12	CAP - BEARING, PUMP SHFT	2304202	1
13	VENT	4403400	1
14	HMCs - .375-16 x 1.00, GR8	5401023	5
15	PLUG - TACH, .685-18UNS	1142101	1
16	OIL SEAL - .375 ID X 0.688 OD	3600924	1
17	NOT - CABLE DRIVE, LDM, 0.104	1141900	1
18	HMCs - .375-16 x 0.85, GR5	3603535	8
19	WASHER - LOCK, 0.375 ID	3603503	16
20	PIN - DOWEL, .250 X 0.82, GR8	3605401	2
21	CAP - BEARING, IDLER, TACH	2303853	1
22	O-RING - 3.50 x 3.69 x 0.19	3601724	2
23	BEARING - 22206 PC-3	1723800	2
24	KEY - .50 - .28 x 2.50	3602418	1
25	SHFT - IDLER GEAR, N	5009201	1
26	GEAR - DRIVE, PSP, 8DP, 20DEG PA	2713310	1
27	SPACER - 1.75 x 2.0 x 1.43	3308702	1
28	SPACER - 1.19 x 2.00 x .75	3302204	1
29	BEARING CAP, IDLER	3303332	1
30	SOLE - WATER, DOWN/UP	3601620	2
31	500 YOKE	4813620	1
32	500 YOKE	4813620	2
33	SLINGER - WATER	3704100	2
34	OIL SEAL - 2.89 ID X 3.716 OD	3605403	4
35	HMCs - .375-16 x 1.25, GR5	5400937	2
36	BRACKET - BEARING, FRONT, N	2304603	1
37	BEARING-BALL, 2135FF	1721403	1
38	RING - RETAINER, 5160-9T	3606003	1
39	O-RING - 0.88 x 1.12 x 0.12	3601212	1
40	DIPSTICK - 20X2.2-5 THRD	4219000	1
41	O-RING - 20MM X 2.5MM X 2.5MM	3601702	1
42	PLUG - PIPE, 0.315, MAG SOC HD	1080510	1
43	SHIFT BAR - PSM	1183300	1
44	PELLET - OIL WICK	4400900	6
45	SHIFT YOKE	1183700	1
46	LOCK BOLT - SHIFT BAR	1184000	1
47	WIRE - SAFETY	1102619	1
48	SPACER - 2.56 x 2.88 x 1.38	3304704	1
49	RING - RETAINER, M5000-393	3600438	1
50	BEARING-BALL, 112ASFF	1723400	2
51	SHFT - TRANSMISSION	5009701	1
52	GEAR - DRIVE, N, 8DP, 20 DEGREE PA	2716107	1
53	GEAR - SLIDING CLUTCH, N	2410800	1
54	BEARING-BALL, 3035FF	1721700	1
55	SHFT - TRANSMISSION	5009500	1
56	BEARING-BALL, 112ASCO	1723502	1
57	OIL SEAL - 2.750 ID X 3.305 OD	3600511	2
58	BRACKET - BEARING, REAR NO BRK	2304700	1
59	WASHER - LOCK, HC, 0.375 ID	3603512	8
60	HMCs - .375-16 x 1.25, GR8	5401024	7
61	WASHER - 2.56 x 3.00 x .09 STL	3603023	1
62	BEARING-BALL, 2135FF	1721400	1
63	O-RING - 4.50 x 4.69 x 0.09	3601105	1
64	REAR BEARING CAP, N	2305106	1
65	HMCs - .375-16 x 1.75, GR5	5400039	4
100	HEAD - SUCTION, LDM, MECH SEAL	2807700	1
101	OIL SEAL - 1.875 ID X 3.005 OD	5008303	1
102	SHFT - PUMP, LDM	5400039	1
103	TRANSMISSION COVER ASSEMBLY	AM01301	1
104	AIR CYLINDER - 1.75 BORE	AY00201	1

REV. NO. 1
DATE 27 JUN 2003
271
D

DESIGNER: M.S. Dwyer & Co.
DRAWN: M.S. Dwyer & Co.
CHECKED: M.S. Dwyer & Co.
DATE REVISION: 27 JUN 2003

REVISIONS


TOLERANCE
ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED

REMOVE SHARP EDGES
ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED

DO NOT SCALE DRAWING

DLC0608

REVISIONS			
LTR	DESCRIPTION	DATE	CHG NO.



REMOVE SHARP EDGES

INCH
[MILLIMETER]



W.S. DARLEY & CO.
MELROSE PARK, IL - CHIPPEWA FALLS, WI
OIL SEAL ASSEMBLY TOOL

TOLERANCE
EXCEPT
AS NOTED
.00 ±.03
.000 ±.010
ANGLES ±1°

DR'N S. LEE
CHKD CKE
TRCD

OLD PART NO. —
PATTERN NO. —

MATERIAL NO.
1100613

DO NOT SCALE PRINT


MATERIAL DESCRIPTION:
.875 X 3.12 360 BRASS

ALL DIMENSIONS IN
INCHES UNLESS NOTED

THIS DESIGN IS THE PROPERTY OF
W.S. DARLEY AND CO. - UNAUTHORIZED
REPRODUCTION IS PROHIBITED

DATE MAY6,02
SCALE 1/1

X3852-1



MATERIAL: 3/8" OD X 1 5/8" LG 360 BRASS 1 PATTERN NO. 1100606

THIS DESIGN IS THE PROPERTY OF
W.S. DARLEY AND CO. - UNAUTHORIZED
REPRODUCTION IS PROHIBITED

ALL DIMENSIONS IN
INCHES UNLESS NOTED

DO NOT SCALE PRINT

PART NO. DATE CHANGE
TOLERANCE EXCEPT AS NOTED
FRAC DIM ±.01
.00 ±.01
.000 ±.005
ANGLES ±1'

W.S. DARLEY & CO.
MELROSE PARK, IL - CHIPPEWA FALLS, WI


OIL SEAL ASSEMBLY
PLUG

DR'N JCM
CHKD
TRGD

DATE FEB9,88

SCALE 2/1

X3852



X3851-1	2-9-88	B=2.562/2.564 A=2.750/2.745
PART NO.	DATE	CHANGE
TOLERANCE EXCEPT AS NOTED		
FRAC DIM ±.01		
.000 ±.005		
ANGLES ±1°		
DR'N JCM	DATE FEB9,88	X3851
CHKD	SCALE 1/1	
TRCD		



MATERIAL: 2 3/8" OD X 1" LG CRS
 2 3/4" OD X 1" LG CRS FOR -1


PATTERN NO.

THIS DESIGN IS THE PROPERTY OF W.S. DARLEY AND CO. - UNAUTHORIZED REPRODUCTION IS PROHIBITED

ALL DIMENSIONS IN INCHES UNLESS NOTED

DO NOT SCALE PRINT

REVISIONS			
LTR	DESCRIPTION	DATE	CHG NO. APPR'D



REMOVE SHARP EDGES

THIRD ANGLE PROJECTION
INCH
[MILLIMETER]

W.S. DARLEY & CO.
MELROSE PARK, IL - CHIPPEWA FALLS, WI
LDM STUFFING BOX ASSY TOOL
2153601 & 2153602

TOLERANCE
EXCEPT AS NOTED
.00 ±.03
.000 ±.010
ANGLES ±1°

OLD PART NO. —
PATTERN NO. —
MATERIAL NO. —

DATE 12DEC,2003
SCALE 1/1


DR'N CKE
CHKD SJJ
TRCD

DO NOT SCALE PRINT

MATERIAL DESCRIPTION:
BAR - ROUND, $\phi 2.12 \times 2.88$ LONG, CRS
ALL DIMENSIONS IN INCHES UNLESS NOTED
THIS DESIGN IS THE PROPERTY OF W.S. DARLEY AND CO. - UNAUTHORIZED REPRODUCTION IS PROHIBITED

X5950

REVISIONS			
LTR	DESCRIPTION	DATE	CHG NO. APPR'D



REMOVE SHARP EDGES

THIRD ANGLE PROJECTION
INCH
[MILLIMETER]

W.S. DARLEY & Co.
MELROSE PARK, IL - CHIPPEWA FALLS, WI
BEARING SUPPORT WASHER
MIDSHIP ASSEMBLY TOOL

TOLERANCE
EXCEPT
AS NOTED
.00 ±.03
.000 ±.010
ANGLES ±1°

DR'N S'JL
CHKD GDZ
TRCD

DATE 10NOV,05
SCALE 1/1

OLD PART NO. —
PATTERN NO. —

MATERIAL NO. 1100013

DO NOT SCALE PRINT

2.50 DIA CRS
ALL DIMENSIONS IN INCHES UNLESS NOTED

THIS DESIGN IS THE PROPERTY OF W.S. DARLEY AND CO. - UNAUTHORIZED REPRODUCTION IS PROHIBITED

X5144-2



W. S. DARLEY & CO.

DARLEY INJECTION TYPE STUFFING BOX ADJUSTMENT

⚠ Prop 65 Warning: This product contains lead, a chemical known to the State of California to cause cancer, birth defects, and other reproductive harm. Wash hands after handling.


⚠ Caution: Do not attempt to use anything but Darley injection packing. Using the wrong packing material in your pump may cause catastrophic failure of the pump shaft sealing components.

Only use W.S. Darley & Co.'s plastallic injection packing material. It is made of a special composition of shredded fibers, and a special bonding and lubricating compound.

It is important that the stuffing box is completely filled solid with packing and compressed firm during adjustment to prevent formation of voids and excessive leakage.

To pack the stuffing box when empty and assembled in the pump, remove the packing screw and nut assembly, and insert pellet form packing into the packing plunger guide. Replace the packing screw assembly and use a hand speed wrench to force the pellets into the gland. **DO NOT USE A POWER TOOL!** Repeat pellet additions while turning the impeller shaft by hand until resistance to turning is felt when the stuffing box is almost full. Continue turning packing screw by hand using a standard 6" long 9/16" end wrench until 4 lb. of force is felt at the end of the wrench. This is equivalent to 2 ft-lb or 24 in-lb torque. Continue turning until a few flakes of packing are extruded out the opening between the impeller shaft and the stuffing box hole. The gland is now ready for pressure testing or pumping.

After priming the pump with water, start the pump and raise the discharge pressure to 50 psi. Tighten the packing screw using a 6" long 9/16" end wrench until 4 lb. force is felt at the end of the wrench (24 in-lb torque). Continue operating the pump at 50 psi for 5 minutes to dissipate packing pressure against the shaft and permit cooling water to flow between the shaft and stuffing box hole. Make sure that water actually does come through before operating pump at any higher pressure. The normal drip rate may vary between 5 and 60 drops per minute.



Operate the pump for 10 minutes at the highest normal operating pressure flowing sufficient water to prevent overheating. Do not run the pump blocked tight. Lower discharge pressure to 50 psi and repeat the packing screw tightening procedure outlined above.

The pump may now be operated for any time period required within its rated capacity. However, the drip rate should be monitored more frequently during the first few hours, and adjusted if necessary to achieve a stable flow rate. Several more adjustments may be required.



For a list of approximate quantity of packing pellets required by model (completely repacked), see below:

Model	Approximate # Packing Pellets
A	6
2BE	6
EM	15
H	8
JM	8
KD	10
KS	8
LD	15
LS	9
P	10
U2	5
U4	10

If further information is needed, call **W.S. DARLEY & CO.**
at Chippewa Falls, WI. at 800-634-7812 or 715-726-2650