

## Ohler Model B420 Parts List

Item Number	Part Number	Qty Required	Description of Part
101	C181	1	Pump Case
102	C285-1	1	Wear Plate
103	C182A	1	Impeller
104	C727	2	4 X 9 Flange
105	C187A	1	Clean Out Plate
106	C298-1	1	Adapter Plate
*	C186A	1	Fill Plate
201	C195	1	Support Head
202	C196	1	Bearing Cap - Impeller End
203	C199	1	Bearing Cap - Coupling End
204	309NP	1	Ball Bearing
205	W309P	1	Ball Bearing
206	D184	1	Shaft
207	D320	1	Slinger
208	B2303	1	Grease Cup
209	B2302	1	Nipple
210	C539	1	Impeller Nut
310	C173	2	Seal Plate
311	B109	1	Seal
**	K109	1	Seal Kit
401	C284	1	Check Valve Plate
402	C269	1	Check Valve Hinge
403	D183	1	Check Valve Hinge Pin
404	C171	1	Check Valve Weight
405	C407	1	Check Valve Retainer
406	D203	1	Check Valve Flapper
407	C268	1	Check Valve Body
501	D1018	1	Flange Gasket
502	D1018	1	Flange Gasket
503	D1018	1	Flange Gasket
504	D1030	1 - 3	Adapter Plate Gasket
505	D1023	2 - 4	Bearing Cap Gasket
506	D1021	1	Clean Out Gasket
*	D1020	1	Fill Plate Gasket

\* Parts Not Illustrated

\*\* Kit includes Seal, Seal Plates and Seal Plate Mounting Screws

# Ohler Model B420 Parts Diagram

