



MODEL 3600

## MODEL 3600 PARTS LIST

ITEM	QTY.	PART NO.	DESCRIPTION
1.	1	1310	FRAME AND BODY
2.	1	1364	COUNTER WEIGHT COVER
3.	1	1393	18 HP TWIN CYLINDER ENGINE
4.	1	1392	FLEX CONNECTOR
5.	1	1391	HYDRAULIC PUMP MOUNT
6.	1	1314	BRACKET, SOLENOID
7.	1	1168	SOLENOID, THROTTLE
8.	1	1136	FILLER, HYDRAULIC RESERVOIR
9.	1	1108	12 VOLT BATTERY
10.	1	1354	COVER, BATTERY BOX
11.	2	1102	SPROCKET - 50B14
12.	2	1103	CHAIN # 50
13.	1	1104	SPROCKET - 50A60
14.	1	1308	REEL HUB
15.	1	1057	REEL FLANGE, INNER
16.	1	1307	REEL SHAFT
17.	2	1313	BEARING STRIP, REEL SHAFT
18.	1	1322	MACHINERY BUSHING
19.	5	1323	O'RING, REEL SHAFT
20.	5	1324	BACK UP RING, REEL SHAFT
21.	1	1122	BOOM EXTENSION
22.	1	1357	MACHINERY BUSHING
23.	2	1358	BEARING - FLANGE
24.	1	1249	HOSE GUIDE
25.	3	1356	ROLLER - HOLE GUARD
26.	1	1355	HOLE GUARD BODY
27.	1	1241	PIN
28.	1	1288	TILLER ASSEMBLY
29.	1	1224	FRONT FORK ASSEMBLY
30.	2	1359	BEARING, SELF ALIGNING
31.	1	1363	WASHER, SPRING
32.	1	1133	TILLER ADAPTOR
33.	1	1106	HUB WITH BEARING, FRONT
34.	1	1162	18 x 9.50-8 RIBBED TIRE & WHEEL

## MODEL 3600 PARTS LIST

35.	2	1099	18 x 9.50-8 TRACTION TIRE & WHEEL
36.	2	1145	REAR DRIVE HUB
37.	2	1120	CLUTCH HUB
38.	2	1362	BEARING - PILLOW BLOCK
39.	1	1076	AXLE
40.	1	1147	SPROCKET 50B21
41.	1	1274	ELECTRICAL CONTROL BOX
42.	1	1306	ELECTRIC FUEL PUMP (BRIGGS ENGINES)
43.	1	1113	OUTER REEL FLANGE
44.	1	1309	COLLAR REEL SHAFT
45.	2	1361	MACHINERY BUSHING
46.	1	1365	REEL SCROLL