

## T24 - T36

### ENGINE DRIVEN TRASH-FLO PUMP

ITEM NUMBER	PART NUMBER	QTY	DESCRIPTION	REMARKS
1	C413	1	Support bracket	
2	C541	1	Pump case	
3	C542	1	Impeller	
4	C544A	1	Clean out	
5	C545	1	Wear plate	
6	C546	1	Clean out handle	
<i>Not shown</i>	C129	1	2" NPT inlet flange	<i>T24</i>
<i>Not shown</i>	C129-1	1	2" NPT outlet flange	<i>optional--T24</i>
<i>Not shown</i>	C130	1	2" NPT discharge tee	<i>standard--T24</i>
7	C149	1	3" NPT inlet flange	<i>T36</i>
<i>Not shown</i>	C149-1	1	3" NPT outlet flange	<i>optional--T36</i>
<i>Not shown</i>	C157	1	3" NPT discharge tee	<i>standard--T36</i>
8	A125V	1	Viton seal kit	
9	B152	1	O-ring	
10	B215	2	3/8-16 x 3 3/4 stud bolt	
11	B216	2	3/8-16 handle nut	
<i>Not shown</i>	D342	2	3" x 3" coupling nipple	
12	D343	1	Shaft extension (5/8-18 to 1"-14 thread)	<i>Not used on certain models</i>
<i>Not shown</i>	D346	1	Tubular roll cage	
13	D1002	1-3	Case gasket	
14	D1013	2	Flange gasket	

# T24 - T36 ENGINE DRIVEN TRASH-FLO PUMP

